

## EP.L3800 Elevator Control Panel

### ACCESSORIES



Biometrics Reader




RFID Reader



HIO



HIO.EXP



- Support 8 floors by default (expendable to 136 Floors max.)
- Support timezone control bypass for individual floor
- Support up to 4 readers max.
- Support both RFID & biometrics readers
- Emergency bypass function by software
- Emergency bypass function by key Switch


### Ordering Information

EP.L3800.PSU

Entrypass 4 Readers Advanced Serial Elevator Control Panel with Power Supply Unit



## Basic System Diagram



### DCAM TECHNOLOGY (M) SDN BHD

No. 48-1, Jalan PBS 14/3, Kawasan Perindustrian Bukit Serdang,  
 43300 Seri Kembangan, Selangor Darul Ehsan, Malaysia.  
 Tel : +603-8948 5707      Email : danny@dcam.com.my  
 Fax : +603-8948 4121      Website : www.dcam.com.my

Product specification and availability subject to change without notice. Certain product names mentioned herein may be trade names and/or registered trademarks of other companies.